
## **Set Up Instructions**

- 1. Select a dry, flat area, making sure it is large enough to accommodate the entire unit, as well as an additional 5' clearance on top and all four sides of the unit.
- 2. Make sure the location is away from tree branches, bushes, food & beverage tables, power lines, and pets. Clear away all debris that may damage the bottom of the unit
- 3. Make sure the location you select is near an electrical outlet. If no outlet is available you will need a generator. Length of extension cord needed\_\_\_\_\_. Amperage required\_\_\_\_\_. Proper gauge\_\_\_\_\_.
- 4. When setting up the unit, it is recommended that a tarp be placed under the unit. Make sure you identify all underground electric, gas, and water lines prior to setup.
- 5. Using the attached anchor rings and 4 ground stakes that are provided with each unit, securely stake down EACH attachment snugged at a 5 degree angle.



- 6. Make sure all electrical plugs are secure in their outlets prior to inflating the unit.
- 7. Connect the air inflation tube to the fan, using the support strap provided. Make sure any other tubes are sealed and all zippers are zipped. Once the units is completely inflated, check to make sure there are no sagging/collapsing pillars or beams and that all sections of the bounce surface are securely inflated.

## Safety Instructions

- TRAINED ADULT SUPERVISION must be maintained at all times. The bounce house should never be left unattended while IN USE or inflated.
- The correct number of operators must always be present with the unit (at least 1 adult). DO NOT allow children to play on the inflatable without adult supervision. Adult supervision is necessary to enforce these rules for safe operation of the inflatable.
- NO FOOD OR BEVERAGES IN THE BOUNCE HOUSE AT ANY TIME.
- NO SHOES or sharp objects should be used in the bounce house at any time.
- It is recommended that all bouncers empty their pockets before entering the bounce house.
- All bouncers should remove eyeglasses, jewelry and any other hard or sharp objects before entering the bounce house.
- NO FLIPS, WRESTLING OR ANY OTHER FORMS OF ROUGH HOUSING should be allowed in the bounce house.
- DO NOT allow bouncers to run into and/or bounce against the walls or support pillars of the bounce house.
- DO NOT allow bouncers to run or jump through the entrance of the bounce house. It is recommended that all bouncers enter and exit the bounce house in a seated position.
- Bouncers should be grouped according to age and size. Ages 3 and up only. No Adults. No Pets.
- DO NOT allow any climbing or hanging on any interior or exterior surface of the bounce house.
- DO NOT USE THE BOUNCE HOUSE IN THE RAIN OR STORM. The jumping surface becomes very slippery when wet. In the event of rain or lightning, all bouncers should exit the unit. The bounce house should then be deflated by switching the blower motor power to the OFF position and unplug it.
- Have Children Evacuate Immediately if the Inflatable Bouncer Loses Air.

 Use caution when wind speeds become Moderate (13-18mph) DO NOT use the bounce house in Fresh winds (19+ mph). Please refer to the Wind Force Scale at the end of this manual. Should it become Fresh-Strong winds or more during operation, remove all children from the bounce house immediately and deflate completely.

	·		
BEAUFORT NUMBER	WIND	SYMBOL	WIND SPEED (MPH)
0	calm	0	less than 1
1	light air	0	1-3
2	slight breeze	0.1	4-7
3	gentle breeze	0 7	8-12
4	moderate breeze	0 11	13-18
5	fresh breeze	O III	19-24
6	strong breeze	0 111	25-31
7	moderate gale	0 1111	32-38
8	Iresh gale	0 1111	39-46
9	strong gale	O min	47-54
10	whole gale	OIIII	55-63
11	storm	חוווי ס	64-75
12	hurricane	O IIIII	more than 75

\*\*\*\*\*I have been given instructions for setup, take-down, and operation of all equipment rented and I accept full responsibility for said equipment. I acknowledge that I have been informed if I have any questions to call an on-duty staff member at the following number:

Print name:

Signature:

Phone Number:

Email address:

## Play at your own risk

Lessor will not be responsible for any incidents or accidents that may occur on the equipment.

Children may not be left unattended. All children must be supervised by a parent or guardian.